INDEX - TR

• Theory •

• Removal •

• Adjustment •

REMOVAL - TR

Title	Section	Page No.
[A]		
ADF Cover	Maintenance	1-6
ADF Unit Cover	Maintenance	1-6
[B]		
Back Cover	Maintenance	1-6
[C]		
Clamp Motor	Master Clamp	10-8
Clamp Sensor A	Master Clamp	10-8
Clamp Sensor B	Master Clamp	10-8
Clamp Unit	Master Clamp	10-7
Compressing Motor	Master Removal	11-15
Cutter Unit	Cutter	13-5
[D]		
Drum Body	Drum	8-10
Drum Cover	Maintenance	1-6
Drum Safety Switch	Main Drive	3-12
Drum Set Sensor	Drum	8-20
Drum Support F & Drum Support R	Drum	8-15
[E]		
Elevator Motor Unit	First paper Feed	4-14
[F]		
Front Cover	Maintenance	1-5
[G]		
G-Belts on Vertical Transport Roller (down)	Master Removal	11-21
G-Belts on Vertical Transport Roller (up)	Master Removal	11-19
[I]		
Image Scanner Unit	Image Scanning	12-8
Ink Pack Set Sensor	Drum	8-20
Ink Pump Unit	Drum	8-18
Ink Sensor PCB	Drum	8-12
Inking Motor	Drum	8-19
Intermediate Gear	Main Drive	3-9
[L]		
Load Spring	Second Paper Feed	5-5
[M]		
Main Motor Unit	Main Drive	3-7
Main PCB and Power Supply PCB Bracket Frames	Maintenance	1-9
Main PCB Bracket Frame	Maintenance	1-7
Master Compress Plate	Master Removal	11-22
Master Compressing Sensor	Master Removal	11-18
Master End Sensor	Master Clamping/Loading	15-26
Master Full Det. Sensor	Master Removal	11-18
Master Loading Clutch	Master Clamping/Loading	15-25
Master Making Unit	Master Clamping/Loading	15-17
Master Making Unit Cover	Maintenance	1-6
Master Making Unit Safety Switch	Main Drive	3-11

REMOVAL - TR

Title	Section	Page No.
[M]		
Master Making Unit Set Switch	Master Clamping/Loading	15-19
Master Making Upper Unit	Master Clamping/Loading	15-21
Master Positioning Sensor	Master Clamping/Loading	15-23
Master Removal Hook	Master Removal	11-20
Master Removal Lower Cover	Maintenance	1-5
Master Removal Motor	Master Removal	11-16
Master Removal Sensor	Master Removal	11-18
Master Removal Unit	Master Removal	11-13
Master Removal Unit Safety Switch	Main Drive	3-10
Master Removal Upper Cover	Maintenance	1-5
Master Sensor	Master Removal	11-20
Master Tension Plate Sensor	Master Clamping/Loading	15-24
Master Tension Plate Solenoid	Master Clamping/Loading	15-25
[O]		
Original Detection Sensor	Image Scanning	12-9
Original Feed Solenoid	Image Scanning	12-7
Original IN Sensor	Image Scanning	12-9
[P]		
Paper Detection Sensor	First paper Feed	4-8
Paper Ejection Motor	Paper Ejection	7-8
Paper Feed Clutch	First paper Feed	4-12
Paper Feed Tray Unit	First paper Feed	4-7
Paper Guide Plate	Second Paper Feed	5-10
Paper Receiving Sensor	Paper Ejection	7-10
Paper Receiving Tray	Paper Ejection	7-13
Paper Sensor	Second Paper Feed	5-12
Pickup Roller	Image Scanning	12-10
Power Supply PCB Bracket Frame	Maintenance	1-8
Pressure Lever Ass'y	Press	6-6
Pressure Roller	Press	6-5
Pressure Shaft Ass'y	Press	6-8
Pressure Solenoid	Press	6-9
Print Positioning Pulse Motor	Second Paper Feed	5-9
Print Positioning Unit	Second Paper Feed	5-8
Pulley Shaft	Master Removal	11-19
[R]		
Read Pulse Motor	Image Scanning	12-12
[S]		
Scraper and Pickup Rollers	First paper Feed	4-9
Scraper Assembly	First paper Feed	4-13
Screen	Drum	8-9
Sector Gear	Second Paper Feed	5-7
Separation Fan	Paper Ejection	7-10
Separation Fan Unit	Paper Ejection	7-9
Separator	Paper Ejection	7-11
Squeegee Roller	Drum	8-13

REMOVAL - TR

Title	Section	Page No.
[S]		
Stripper Pad	First paper Feed	4-10
Stripper Pad Ass'y	Image Scanning	12-11
Stripper Roller	Image Scanning	12-10
Suction Fan	Paper Ejection	7-8
Suction Unit	Paper Ejection	7-5
[T]		
Thermal Print Head (TPH)	Master Making	14-6
Timing Cam	Second Paper Feed	5-6
Timing Roller	Second Paper Feed	5-13
Transfer Belt	Paper Ejection	7-6
[U]		
Upper Limit Sensor	First paper Feed	4-11
[V]		
Vertical Transport Roller (down)	Master Removal	11-21
Vertical Transport Roller (up)	Master Removal	11-19
[W]		
Write Pulse Motor	Master Clamping/Loading	15-20
Write Roller	Master Making	14-5